



Move J1 jumper to left to disable PIC on all boards except the one connected to a PC

9 jumpers connecting boards together

Put jumper on J7 of all boards except one to disable 16MHz osc

9 jumpers connecting boards together

Jumper should be off J7 one one board only



Jumper J1 to the right

Remove CS1 jumper from J7 on all boards except the first board (on the right)

This board has default jumper settings

Common up power & ground to all boards. Make leads as short as possible

Power

Add extra ground links between the boards, the more the better. Make these links as short as possible.